



DMX CHART – LUXIBEL B PANEL240CW

1 Channel Mode

Channel	Value	Function
CH 1	0-255	Dimmer Fine 0-100%

2 Channel Mode

Channel	Value	Function
CH 1	0-255	Dimmer Fine 0-100%
CH 2	0-255	Strobe 1/sec -> burst

3 Channel Mode

Channel	Value	Function
CH 1	0-255	Dimmer Fine 0-100%
CH 2	0-255	Dimmer Coarse 0-100%
CH 3	0-255	Strobe 1/sec -> burst