



DMX CHART – LUXIBEL B PANEL180TW

2-Channel Mode

Channel	Value	Function
CH 1	0-255	Dimmer
CH 2	0-255	CCT

3-Channel Mode

Channel	Value	Function
CH 1	0-255	Coarse dimmer
CH 2	0-255	Fine dimmer
CH 3	0-255	CCT

6-Channel Mode

Channel	Value	Function
CH 1	0-255	Coarse dimmer
CH 2	0-255	Fine dimmer
CH 3	0-255	CCT
CH 4	0-255	Strobe
CH 5	0-28 29-57 58-86 87-114 115-144 145-173 174-201 202-231 231-255	Frequency preset: 1.000 Hz Frequency preset: 2.500 Hz Frequency preset: 2.800 Hz Frequency preset: 3.300 Hz Frequency preset: 4.000 Hz Frequency preset: 5.000 Hz Frequency preset: 6.600 Hz Frequency preset: 10.000 Hz Frequency preset: 20.000 Hz
CH 6	0-63 64-127 128-191 192-255	Inverse square law Linear Square law S Curve

8-Channel Mode

Channel	Value	Function
CH 1	0-255	Coarse dimmer
CH 2	0-255	Fine dimmer

CH 3	0-255	CCT
CH 4	0-255	Strobe
CH 5	0-28 29-57 58-86 87-114 115-144 145-173 174-201 202-231 231-255	Frequency preset: 1.000 Hz Frequency preset: 2.500 Hz Frequency preset: 2.800 Hz Frequency preset: 3.300 Hz Frequency preset: 4.000 Hz Frequency preset: 5.000 Hz Frequency preset: 6.600 Hz Frequency preset: 10.000 Hz Frequency preset: 20.000 Hz
CH 6	0-63 64-127 128-191 192-255	Inverse square law Linear Square law S Curve
CH 7	0-255	CW Dimmer
CH 8	0-255	WW Dimmer