



## DMX CHART – LUXIBEL B PANEL360TW

### 2-Channel Mode

Channel	Value	Function
CH 1	0-255	Dimmer
CH 2	0-255	CCT

### 3-Channel Mode

Channel	Value	Function
CH 1	0-255	Coarse dimmer
CH 2	0-255	Fine dimmer
CH 3	0-255	CCT

### 6-Channel Mode

Channel	Value	Function
CH 1	0-255	Coarse dimmer
CH 2	0-255	Fine dimmer
CH 3	0-255	CCT
CH 4	0-255	Strobe
CH 5	0-28	Frequency preset: 1.000 Hz
	29-57	Frequency preset: 2.500 Hz
	58-86	Frequency preset: 2.800 Hz
	87-114	Frequency preset: 3.300 Hz
	115-144	Frequency preset: 4.000 Hz
	145-173	Frequency preset: 5.000 Hz
	174-201	Frequency preset: 6.600 Hz
	202-231	Frequency preset: 10.000 Hz
231-255	Frequency preset: 20.000 Hz	
CH 6	0-63	Inverse square law
	64-127	Linear
	128-191	Square law
	192-255	S Curve